# **Smart Valve Positioner**



# 6000 Series Instruction Manual







# **Table of Contents**

1	Intr	oduction	4		
	1.1	General information for the user	4		
	1.2	Requirement for safety	5		
	1.3		6		
		1.3.1 Conditions to maintain intrinsic safety (Ex i)	6		
			6		
2	Des	scription of products	7		
	2.1	Function	7		
	2.2	Features	7		
	2.3	Options	7		
	2.4	Applications	7		
	2.5	Name plats	8		
	2.6	Products number	9		
	2.7	Specifications	10		
	2.8	Structure	11		
		2.8.1 External structure	11		
		2.8.2 Internal structure	12		
	2.9	System configuration	13		
	2.1	Principle of operation			
	2.11	Dimension drawings	14		
		2.11.1 6000 standard type	14		
		2.11.2 6000 with limit switch type	14		
		2.11.3 6000 feedback shaft connection	14		
3	Inst	tallationtallation	15		
	3.1	Before installation	15		
	3.2	6000L installation	15		
		3.2.1 Notes on installation	15		
		3.2.2 Effective rotation angle of feedback lever	16		
		3.2.3 Lever type and dimensions	16		
		3.2.4 Bracket installation	17		
		3.2.5 Dimension after installation	17		
	3.3	6000R installation	18		
		3.3.1 6000R installation examples	18		
		3.3.1 List of supplied installation parts	18		
		3.3.3 6000R installation steps	19		
	3.4	6020 Remote type installation	21		
	3.5	Installation of option modules	22		
		3.5.1 Installation of Position transmitter module	22		



		3.5.2	Installation of HART communication module	22			
		3.5.3	Installation of Limit switch modules	23			
		3.5.4	How to adjust limit switch cam	24			
	3.6	How to	adjust Auto/Manual switch	25			
	3.7	Orifice	installation	26			
4	Pne	eumat	tic connection	27			
	4.1	Conditi	ion of air supply	27			
	4.2	Descri	ption of air ports	27			
	4.3	Air con	nnection	28			
		4.3.1	6000L air connection	28			
		4.3.2	6000R air connection	28			
5	Ele	ctrica	I connections	29			
	5.1	Termin	nal description	29			
	5.2	Wiring	diagrams	30			
		5.2.1	Power and Feedback signal connections	30			
		5.2.2	Limit switch connection	30			
		5.2.3	Alarm signal connection	30			
6	Cal	Calibration					
	6.1	Descri	ption of Display	32			
	6.2	-	ption of Buttons	29			
	6.3	How to	perform fast auto calibration	33			
		6.3.1	Steps of auto calibration	33			
	6.4	Softwa	are map	34			
	6.5	Descri	ption of Main menus	35			
	6.6	Descri	ption of Main parameters	36			
	6.7	Descri	ption of Submenus	37			
		6.7.1	TUNING	37			
		6.7.2	PARAMETE	39			
		6.7.3	DEVICE P	41			
		6.7.4	INFOMATN	44			
		6.7.5	DIAGNOST	45			
		6.7.6	EMERGNCy	48			
7	Err	or cod	de and Troubleshooting	49			
8	Lin	nited v	warranty and disclaimer	50			



## 1 Introduction

#### 1.1 General information for the user

This instruction includes installation, operation, maintenance, and parts information for 6000 Series Valve Positioner. Keep these instructions in a location which is easily accessible to every user and make these instructions available to every new owner of the device. □

- Installation, commissioning and maintenance of the product can only be performed by trained specialist personnel who have been authorized by the plant operator to do so.
- To avoid possible injury to the personnel or damage to valve parts, WARNING, CAUTION and NOTICE must be strictly followed.
- Before installing or commissioning, be sure to read and thoroughly understand the product manual and operate the product properly.
- Operators must strictly observe the applicable national regulations with regards to installation, function tests, repairs, and maintenance of electrical products.
- For additional information or if specific problems occur that are not explained in these instructions, contact the manufacturer.

The manual can be altered or revised due to hardware of software upgrades without any prior notice. Please visit our website ( www.jflowcontrols.com ) and check the latest documentation.

Manual version	PM-6000EN-8/2017
Software version	V.1.0



## 1.2 Requirements for safety

This manual contains notices you have to observe in order to ensure your personal safety, as well as to prevent damage to property. These safety instructions are intended to prevent hazardous situations and/or equipment damage. For the safety, it is important to follow the instructions in the manual.

# **MARNING**

Failure to observe the warning may result in serious injuries or death.

# **A** CAUTION

Failure to observe this warning may result in damage to the device or personal injury.

# **№** NOTICE

Failure to observe the warning may result in damage to the device or may degrade performance.

#### Safety notes

# **CAUTION**

- Only trained and authorized person should operate the machinery and the equipment.
- Do not use this positioner out of the range of its specifications as this can cause failure.
- Do not service or attempt to remove product and machinery/equipment until safety is confirmed.
- Never handle mechanical equipment or disassemble the device until safety is confirmed.
- Before loosening the pneumatic lines and valves, turn off the pressure and vent the pneumatic lines.
- Before reaching into the device or the equipment, switch off the power supply and secure to prevent reactivation.
- Observe applicable accident prevention and the safety regulations for electrical equipment.



## 1.3 Basic safety instructions for use in the Ex area

To prevent the risk of explosion, observe not only the basic safety instructions in the respective operating instructions for operation in the Ex area, but also the following.

# **MARNING**

- Observe the applicable safety regulations (also national safety regulations) as well as the general rules of technology for construction and operation.
- Make sure that the device is suitable for the area of use.
- Check the positioner's certified and permitted explosion proof range.
- Close all unnecessary cable glands with lock screws approved for the explosions area.

## 1.3.1 Conditions to maintain intrinsic safety (Ex i)

# **MARNING**

- Make sure to connect the protection device with type of protection "Intrinsic safety" solely to an intrinsically safe circuit.
- Observe the specifications for the electrical data on the certificate and in technical data.

#### 1.3.2 Data of Intrinsic safety explosion

Explosion regulations	IEC 60079-0:2011 IEC 60079-11:2011					
Explosion proof type	Ex ia IIC T5/T6					
Barrier specifications	Ui	li	Pi	Ci	Li	
Main power	28V	100mA	651mW	0.6nF	300uH	
Feedback signal power	28V	100mA	651mW	0.6nF	300uh	
Limit Switch (Dry contact type)	28V	100mA	651mW	0nF	0uH	



# 2 Description of products

#### 2.1 Function

Smart valve positioner 6000 series controls the valve stroke in response to an input signal of 4~20mA DC from the control panel, DCS or calibrator.

## 2.2 Features

- LCD and 4 button local control
- · Quick and easy calibration
- PST and alarm function
- Auto/Manual switch included
- Built-in self-diagnostic function
- Modularization of the internal parts
- IP66 / NEMA4X
- Improvement of valve control speed by applying large flow pilot valve
- Strong vibration resistance and impact resistance

# 2.3 Options

- Position transmitter(4~20mA DC Feedback signal)
- HART communication (Ver. HART 7)
- Limit switch (Mechanical or Proximity type)
- Remote control type (6020)

## 2.4 Applications

The 6000 is mounted on a pneumatic control valves and is used for fluid control of industrial parts.

- Oil and gas
- Chemicals
- Power plant
- Paper
- Water treatment
- Pharmaceutical
- Printing and dyeing processing
- Food and beverage
- Other



# 2.5 Name plates

TS800	9	Smart Positioner			
MODEL No. SERIAL No. EXPLOSION PROOF. OPERATING TEMP. AMBENT TEMP. WEATHER PROOF INPUT SIGNAL SUPPLY PRESSURE UI, II, PI, CI, LI,	TS800LSn00000 1702200 Ex ia IIIC T5/T6 Gb Ex ia IIIC T100 C / T85 C Db -30°C - +85°C (-22°F ~ +185°F) T5 : -40°C ~ +60°C T6 : -40°C ~ +40°C IP66 4~20mA DC 0.14 ~ 0.7MPa (1.4 ~ 7 bar) See Certificate	C €0000 (Ex) <sub>11 2 G/D</sub> (S SIL2  000 12ATEX 0000 X  114-KB2B0-0000X			
(Bucheon Technopark Ssangyong 3rd, Samjeong-dong) Rm202-801 #397, Seokcheon-ro, Ojeong-gu, Bucheon-si, Gyeonggi-do, Korea Made in Korea  **www.tissin.co.kr					



<6000> <6020>

Item	Description
MODEL No.	Indicates the model number.
SERIAL No.	Indicates the serial number.
EXPLOSION PROOF	Indicates the certified explosion proof grade.
OPRATING TEMP.	Indicates the allowable operating temperature.
AMBENT TEMP.	Indicates the ambient temperature range for the explosion proof. This temperature range must be observed when using in explosion-proof areas.
WEATHER PROOF	Indicates the enclosure grade.
INPUT SIGNAL	Indicates input current signal range.
SUPPLY PRESSURE	Indicates the allowable input supply pressure range.
Ui, Ii, Pi, Ci, Li	Indicates required barrier specification for intrinsically safety circuit configuration.  Please refer to the certificate for the detailed specifications.



#### 2.6 Product number

Model	Standard type	6000-							
Model	Remote type	6020-							
Acting type		0020-							
Acting type	Linear type		L						
Explosion proof	Rotary type		R	]					
type	Non-explosion p	1000		N					
	Ex ia IIC T5/T6			A	]				
Connection type	Conduit entry		conne	<u>ction</u>					
	G(PF)1/2	PT1	/4		1				
	G(PF)1/2	NP	Γ1/4		2				
	NPT1/2	NP	Γ1/4		3				
Lever type (Linear )	10~80mm					1			
,	70~150mm					2			
	Adapter type(70	mm)				3			
Lever type (Rotary)	M6 x 34L (Fork lever type) 1					1			
(Rotary)	NAMUR					5			
Ambient Temp.	-30~85℃ (Standard type)								
	-40~85°C (Low temperature type) L								
Communication*	None							0	
	Position transmi	tter(4~20n	nA DC	<b>C</b> )				1	
	HART							2	
	HART and Posit	ion transn	nitter (	4~20r	nA DC	;)		3	
Limit switch 1)	None				0				
(6000)	Mechanical type	(Dry cont	act No	O, NC	, COM	l)			М
	Proximity type (	Open-colle	ector o	utput	NPN)				Р
	With Dome cover (Without Limit switch)							D	
Cable length <sup>2)</sup>	5m				1				
(6020) 10m							2		
	User define(Les	s than 20	meter	s)					Χ

## Note

- Only for 6000 model.
   Only for 6020 model.



# 2.7 Specifications

Model		6000L / 6020L	6000R / 6020R	
Input sign	al	4~20mA DC		
Impedanc	e	500Ω (20mA DC)		
Supply pro	essure	0.14~0.7MPa		
Stroke		10~150mm	0~900	
Air conne	ction	PT1/4,	NPT1/4	
Gauge co	nnection	PT1/8,	NPT1/8	
Conduit		G(PF)1/2	2, NPT1/2	
Explosion	proof type	Ex ia IIC T5/T6		
Enclosure		IP66		
Ambient	Acting Temp.	-30 °C ~ 85 °C (Standard type), -40 °C ~ 85 °C (Low temp type)		
Temp.	Explosion Temp.	-40 °C ~60 °C (T5) / -40 °C ~40 °C (T6)		
Linearity		±0.5% F.S.		
Sensitivity	,	±0.2% F.S		
Hysteresis	S	±0.5% F.S		
Repeatab	ility	±0.3% F.S		
Air consu	mption	Below 2.3LPM (Sup.=0.14MPa)		
Flow capa	acity	Over 100LPM (Sup.=0.14MPa)		
Material		Aluminum die cast		
Weight		2.	2kg	

# Option specifications


Options	Item	Specification		
HART	HART version	HART 7		
Position transmitter	Wire connection type	2Wire		
Position transmitter	Supply voltage	10~30V DC		
Lineit evoltale	Mechanical type	AC125V 3A, DC30V,2A		
Limit switch	Proximity type	DC8.2V 8.2A		

**Note**: Please contact our sales department for other specifications.



## 2.8 Structure


#### 2.8.1 External structure



**Note:** Only the limit switch type product is equipped with a dome indicator.



## 2.8.2 Internal structure




- 1 Pilot valve
- 2 Potentiometer
- 3 Pressure sensor (Option)
- 4 Torque motor
- (5) Main PCB
- (6) Terminal block
- 7 HART communication module (Option)

- 8 Position transmitter module(Option)
- 9 Buttons
- (10) Alarm signal connection terminal
- (11) PCB cover
- (12) Limit switch connection terminal
- (13) Limit switch (Option)




# 2.9 System configuration

Basically, the control valve system consists of a positioner for controlling the pneumatic pressure of the actuator, an actuator for controlling the opening of the valve, and a valve for controlling the flow of the fluid.



## 2.10 Principle of operation


6000 receives the 4-20mA input signal of the control room, the micro-processor (CPU) compares input signal with position feedback through the potentiometer and sends control signal to the I/P conversion module torque motor, torque motor converts it to a pneumatic signal to control the pilot valve to control the opening of the control valve by converting the output pressure of OUT1 and OUT2.






# 2.11 Dimension drawings


# 2.11.1 6000 standard type



# 2.11.2 6000 with limit switch type



## 2.11.3 6000 feedback shaft connection





# 3 Installation

#### 3.1 Before installation

# **MARING**

- Make sure if 6000 is appropriate to the valve and actuator installation conditions and the site requirements specifications before installation.
- If the installation state is not correct, 6000 control characteristics may be degraded.

## 3.2 6000 installation


#### 3.2.1 Notes on installation

When make the mounting bracket and connecting the lever to the stem connection pin, be sure to observe the following two points.

If not compliance will affect the product performance such as linearity.

# **№** NOTICE

- (1) When the valve stroke is 50%, the feedback lever should be horizontal.
- 2 When the valve stroke is 50%, the stem connection pin must be located at the numeric position marked on the feedback lever that is corresponding to the valve stroke.



- 1 Feedback lever
- ② Stem connection pin
- 3 Pin fixing spring

- (4) Actuator stem
- (5) Valve opening indicator




# 3.2.2 Effective rotation angle range of the feedback lever

The effective rotation angle of 6000L lever is respectively 30° upward and downward that is based on horizon.

Follow 3.2.1notes, effective rotation angle can be maintained to achieve the best performance.

# **№** NOTICE

- If the rotation angle range is too small during operation, the performance of products such as linearity may be degradation.
- If the rotation angle range is too big during operation, may damage the product or cause malfunctions.



#### 3.2.3 Lever type and dimensions


The numeric position marked on the feedback lever correspond to the valve stroke, and the stem connection pin must be connected to the corresponding marked location

Lever No.	Valve stroke	Dimensions
No.1	10~80mm	73.61
No.2	70~150mm	02 08 06 001 011 021 021 01 01 051 138.56
No.3	10~70mm	75




## 3.2.4 Bracket Installation

Refer to the 6000L drawing (refer to 2.10.2) and actuator drawing, and make appropriate bracket and install the positioner on the actuator.




- 1 Bracket
- (2) Bolt (M8)
- (3) Washer
- (4) Feedback lever
- (5) Lever fixing bolt
- (6) Main shaft
- (7) Shaft fixing pin

## 3.2.6 Dimension after installation



<When the lever is No.1 or 2 >



<When the lever is No.3>


- 1 Stem connection pin
- (2) Feedback lever
- (3) Bracket

- 4 Actuator york
- (5) Lever adapter



## 3.3 6000R installation


## 3.3.2 6000R installation examples



## 3.3.3 6000R list of supplied installation parts

When shipped form the factory, parts 1~8 are provided as standard.

The brackets support the NAMUR mounting standard (VDI/VDE3835, IEC60534-6-2).



- 1 Lower bracket(1)
- 2 Upper bracket(1)
- 3 Nuts(4)
- 4 Screws (M6x4)

- 5 Screws (M8x4)
- 6 Fork lever(1)
- 7 NAMUR adapter (1)
- 8 Adapter fixing pin(2)



# 3.3.4 6000R installation steps

1	Lower bracket installation Attach the lower bracket to the actuator and secure it with the screw.	
2	Fork lever installation Insert the fork lever into the actuator stem and tighten with the fixing bolt.	
	Position the start point of the fork lever according to the direction of rotation of the actuator stem.	
3	Tighten upper and lower brackets Connect the upper bracket to the lower bracket attached to the actuator and fasten with the screw.	
	Tighten the bolts to the corresponding holes of 20.30 and 50 depending on the actuator stem height.	50 0 30 20



	I	
	Shaft lever installation  Fork lever type Insert the shaft lever into the main shaft and tighten with the fixing bolt.	
4	NAMR type Insert the NAMUR shaft adapter into main shaft and fix it with two fixing pins.	
5	Attach the positioner to the upper bracket and fix it with screw.  At this time, insert the lever pin at the bottom of the fork lever into the hole of the fork lever attached to the actuator and then align the center.	



## 3.4 6020 Remote type installation


The 6020 is designed cabled to the sensor part and the main body, It is designed to transmit the change of the stem position of the valve to the body through the potentiometer built in the sensor.

#### **Application site**

- Where the valve is located at a high or inaccessible location.
- High temperature environment. (Over than 85°degrees)
- Large vibrating lines.

## Installation

- (1) Install the sensor in the valve, and install the body in the accessible places.
- (2) Please follow the installation instructions of 6000L or 6000R for sensor installation.
- (3) The sensor and the body are connected via cable, the length of cable must not exceed 20M.
- (4) Pneumatic piping should connect the Out port of the main body to the actuator.





- 1 Sensor
- (2) Body
- (3) Cable
- 4 Entry power cable
- 5 Out1 piping

# 3.5 Installation of option modules



According to the site requirements , the following modules can be purchased separately and installed. The corresponding function can be realized by installing modules, and the modules do not affect each other.





<Position transmitter module>


<HART communication module>

#### 3.5.1 Installation of position transmitter module

Open the body cover and PCB cover, and install the position transmitter module to the main PCB as figure below.

## ♠ NOTICE


Be sure to have the feedback zero point setting and end point setting once when you after installing the feedback module. Please refer to page 38 OUT ZERO and OUT END setting method.



- 1) Fixing bolt
- (2) Feedback module
- (3) Module bracket
- (4) Main PCB

#### 3.4.2 Installation of HART communication module

Open the body cover and PCB cover, and install the HART communication module to the main PCB as figure below.





- 1 Fixing bolt
- (2) HART module
- Module bracket
- (4) Main PCB


#### 3.4.3 Installation of limit switch modules.



There are mechanical and proximity two types of limit switch.








<Proximity type module>

## Installation steps

- (1) Open the cover.
- ② Mount the limit switch module in the PCB protective cover groove and fix with fixing bolts.
- 3 Turn the camshaft and mount it to the main shaft.
- Fix the camshaft with fixing bolts.
- (5) Mount the dome indicator to the camshaft.



- 1 Dome indicator
- (2) Bbolt
- (3) Camshaft
- 4 Limit switch module
- Module fixing bolts


## Note

The standard product does not have a dome indicator sight window.

The cover for the limit switch product must also be replaced.

## 3.4.4 How to adjust limit switch cam





The cam position has been set at the factory. If you want to change the cam position, please follow the steps below.

- ① Open the cover and separate the dome indicator referring to the above figure.
- 2 Loosen the fixing bolt slightly with a Phillips screwdriver, but do not separate it.
- 3 Adjust the com 3 and 4 by referring to the following figure below, and adjust the angle so that the switch operates at the desired position.
- (4) After adjusting the angle, tighten the fixing bolt tightly.


Mechanical switch	Proximity switch
<ol> <li>Micro switch 1</li> <li>Micro switch 2</li> <li>Operating cam 1</li> <li>Operating cam 2</li> <li>Fixing screw</li> </ol>	<ul> <li>① Proximity switch 1</li> <li>② Proximity switch 2</li> <li>③ Operating cam1</li> <li>④ Operating cam 2</li> <li>⑤ Fixing screw</li> </ul>

## 3.6 How to adjust Auto/Manual switch



## ♠ WARNING

- Be careful that the valve moves when the Auto/Manual switch is operated.
- Do not exceed the permissible air pressure range since the input air pressure is directly transmitted to the actuator when switching to manual mode.




- (1) Auto/Manual switch
- (2) Lock screw

Description	The Auto/Manual switch acts as a bypass valve.  If set the Auto, control valve opening by positioner.  If set to Manual, the supply pressure input from the regulator is transmitted directly to the actuator regardless of the signal from the positioner
Purpose	<ul> <li>When the control valve fails, set to Manual mode and adjust the output pressure of the regulator, if the valve moves with the pressure change, there is a high possibility of the problem of the positioner, if the valve does not move, there is a high probability that the valve has failed.</li> <li>You can adjust the valve opening with the regulator by switching to Manual mode in case of product installation or field emergency</li> </ul>
Adjustment method	<ul> <li>Turning the Auto/Manual switch fully clockwise with a slotted screwdriver sets the Auto mode, will control the valve with the positioner</li> <li>Turning the Auto/Manual switch counterclockwise several times with a slotted screwdriver sets the Manual mode, and the regulator's air pressure is transmitted directly to the actuator.</li> </ul>
Notes	<ul> <li>The product is set to Auto mode at the factory.</li> <li>Auto/Manual switch works only with single type model.</li> </ul>

## 3.7 Orifice installation





#### <Orifice>


#### **Purpose**

A normal action product does not need to install the orifice, but If the hunting phenomenon occurs after installation on a small actuator, it can be solved by installing an orifice to reduce the output flow of air pressure transmitted to the actuator from the positioner. The hole size of the orifice is 1mm.

#### How to install

As figure below, Insert the orifice into the OUT1 port, and fix it by turning it all the way with a slotted screwdriver

- When used for single type actuator, you only need to install orifice on OUT1 port
- When using for double type actuator, they must be installed on both OUT1 and OUT2 ports.



## Note

Please contact us, if you need any of the above parts.

# 4 Pneumatic connection




# 4.1 Conditions of supply air

# **№** NOTICE

- Use only dehumidified and dust extracted compressed clean air.
- The air pressure input must be equipped with a regulator to supply a constant air pressure.

# 4.2 Description of air ports



- Supply port
- ② OUT1 port
- ③ OUT2 port
- 4 Out1 gauge
- ⑤ Out2 gauge


## 4.3 Air connections




# NOTICE

• This product is designed to increase the air pressure of out1 as the 4 ~ 20mA current input signal increases.

#### 4.3.1 6000L air connections



## 4.3.2 6000R air connections





# 5 Electrical connections



- Be sure to check always that the electrical load is within the stated range on the nameplate. Exceeding the rating might cause a malfunction to circuit boards or burn out electrical components.
- Check polarity of + and exactly and connect wires.

# 5.1 Terminal description






- 1 Input signal (+)
- 2 Input signal (-)
- ③ Internal ground
- 4 Feedback signal (+)
- (5) Feedback signal (-)

- 6 Alarm1 signal (+)
- 7 Alarm1 signal (-)
- 8 Alarm2 signal (+)
- 9 Alarm2 signal (-)
- 10 External ground bolt
- ① Conduit

# 5.2 Wiring diagrams



#### 5.2.1 Power and feedback signal connection






Do not apply 24 VDC Power to the IN + or IN - as this will damgae the circuit.


Apply only to OUT + and OUT - for the Trasmitter feature.

#### 5.2.2 Limit switch connection



## 5.2.3 Alarm signal connection

The alarm module is built in to all products. According to the requirements of the site, you can get the feedback from the emergency alarm signal by wiring as follow.



The alarm circuit is OFF when the system is operating normally.

The alarm circuit turns ON according to the set values as below.


- When the product has seriously problems
- When there is a potential problem
- When the valve is fully open
- · When the valve is fully close

For the setting method refer to < **AL1 URGT>** and < **AL2 URGT>** of page 47.

# 6 Calibration




# 6.1 Description of Display



No.	Displayed contents	Description	
1	Manu information	Displays the running menu. (Main menu, Main parameter, Sub parameter)	
2	Manu's value	Displays the currently parameter value of the menu.	
3	Manu's value unit	Displays the currently menu's value unit.	
		PV	Progress value
4	Menu's value separator	SV	Signal value
	ooparator	MV	Motor control value
5	Progress bar	Displays the progress of the processor in bar form.	
6	Main parameter	Displays the selected main parameter currently.	
7	Parameter bar	Displays the position of the selected main parameter.	
8	Alarm 1	The icon is displayed, when the set value of alarm 1 is satisfied.	
9	Alarm 2	The icon is displayed, when the set value of alarm 2 is satisfied.	
10	HART communication	The icon is displayed, when HART communication is in progress.	
<u>(11)</u>	Error code	The icon is displayed If there is an error during calibration or operation.	
12	Modifying	The icon is displayed, when changing the internal setting values such as parameter modification.	
13)	LOCK	The icon is displayed, when the program is locked.	
<u>(14)</u>	UNLOCK	The icon is displayed, when the program is unlocked.	

# 6.2 Description of Buttons





- ① UP button
- 2 DOWN button
- 3 ENTER button
- 4 ESC button

Button	Descriptions
ENTER	<ul> <li>Execute the functions of the selected menu.</li> <li>Saving the modified parameter values.</li> </ul>
ESC	<ul> <li>Moving from the current menu go back to the upper level menu.</li> <li>Cancel current command.</li> </ul>
UP	<ul> <li>Moving between menus of the same level such as main menu, main parameter, sub parameter.</li> <li>Change to the larger value of the set value of the selected parameter.</li> </ul>
DOWN	<ul> <li>Moving between menus of the same level such as main menu, main parameter, sub parameter.</li> <li>Change to the smaller value of the set value of the selected parameter.</li> </ul>

# 6.3 How to perform the fast auto calibration

Open the cover of the product follow below steps to perform the quick auto calibration.



- 1 Input **4~20mA** of current signal, pressing the **<ENTER>** button for 3seconds.
- When "TUNNIG" is displayed, press the <ENTER> button once.
- When "AUTO RUN" is displayed, press the ENTER button once, and then starts the auto calibration.
- (4) The calibration process may take 1 ~ 3 minutes depending on the valve size.


## 6.3.1 Steps of auto calibration

When auto calibration is progress, it will proceed automatically in the following steps.

Steps	Check point
STEP0	Check the zero point of the valve speed. checked at the reference point of valve stops.
STEP1	Finding a zero point of the valve stroke.
STEP2	Finding a end point of the valve stroke.
STEP3	Measure the time of valve fully open.  Measure the time of the valve takes from full close to full open.
STEP4	Measure the time of valve fully close.  Measure the time of the valve takes from full open to full close.
STEP5	Measure of the Low BIAS Measure the motor signal reference value, when the position of valve at the 25%.
STEP6	Measure of the High BIAS Measure the motor signal reference value, when the position of valve at the 75%.

# 6.4 Software map





# 6.5 Description of Main menus

When the product is booted, <MAIN LIN> is displayed, which shows the current opening of



the valve. Press **<UP>** or **<DOWN>** button to move to the following menu and check the corresponding information.

In the main menu, information such as the valve opening and the magnitude of the input current signal can be checked and the execution of the command or the modification of the parameter value cannot be performed.

Main menus	Description	
	Displayed percentage of current valve opening value Depending on the set value of the flow characteristics, one of the following 5 is displayed.	
	LCD display value	Set flow characteristics
MAIN LIN	MAIN LIN	Linear
	MAIN EQ1	EQ1 (1/25)
	MAIN EQ2	EQ2 (1/50)
	MAIN QO	Quick Open
	MAIN USR	User defined 17 points
MAIN IN %	Displayed the magnitude of input signal that the positioner recognizes as percentage.  If the size of the input signal recognized by the positioner differs from output signal of the DCS or calibrator, check the voltage of the power supply.  If the supply current is normal, please reset the <in zero=""> and <in end=""> values in the <tunning> of main parameter.  Displayed the magnitude of input signal that the positioner recognizes as mA.  If the size of the input signal recognized by the positioner differs from output signal of the DCS or calibrator, check the voltage of</tunning></in></in>	
	<ul> <li>the power supply.</li> <li>If the supply current is normal, please reset the <in zero=""> and <in end=""> values in the <tunning> of main parameter.</tunning></in></in></li> </ul>	
MAIN VEL	Displayed currently operating speed of the valve as numbers.  The numbers between -2047 to +2048 and negative numbers indicate speed at close, and positive numbers indicate speed at open.  O means stop and the larger the absolute value, the faster the speed.	
MAIN DEV %	Displayed current input signal and valve opening value as percentage.  Display percentage of error between the current input signal and valve opening value.  The larger the error, the lower the control characteristic.	

# 6.6 Description of Main parameters



The main parameter menu corresponds to the main menu in which various parameters are classified by function.

- When the product is booted, press and hold the **<ENTER>** button for 3 seconds to enter the main menus.
- Main menu is classified as below and can be moved by pressing <UP> or <DOWN> buttons
- Press the **<ENTER>** button in the corresponding main menu to enter the sub parameter menus.

Main menus	Main functions of Submenu		
TUNING	<ul> <li>Auto calibration.</li> <li>Change position of valve zero and span manually.</li> <li>Change the zero and span of feedback signal manually.</li> </ul>		
PARAMETR	<ul> <li>Setting the Dead band.</li> <li>Change PID values.</li> <li>Change the flow characteristics.</li> </ul>		
DEVICE P	<ul> <li>Setting the Single and Double, according to the actuator types.</li> <li>Setting the Linear and Rotary, according to the actuator types.</li> <li>Setting the signal point of Force Open/Close.</li> <li>Setting the acting type of Direct action/ Reverse action.</li> <li>Change the valve acting speed.</li> </ul>		
INFOMATN	<ul> <li>Display the model of product.</li> <li>Display the versions of device and HART.</li> <li>Display the accumulated time of Open/Close.</li> <li>Display the current ambient temperature, the recorded maximum ambient temperature, and the recorded minimum ambient temperature.</li> </ul>		
DIAGNOST	<ul> <li>Display the error code.</li> <li>Setting the PST function.</li> <li>Setting the Alarm function.</li> </ul>		
EMERGNCy	<ul> <li>In case of emergency, set to forcibly open the valve, or close valve, or maintain current position of the function.</li> <li>Setting the Lock and Unlock function.</li> </ul>		

# 6.7 Description of Submenus



The following is detailed description about the corresponding submenu of the main menu.

- Press **<ENTER>** button in the main menu to enter the submenus.
- Use **<UP>** and **<DOWN>** buttons to move between submenus.

#### 6.7.1 Submenus of TUNNING

Submenus	Description of function		
AUTO RUN		ation m any input signal between 4 and 20 mA. nutes, depending on the valve size.	
	Selects the auto call t is set to normal m		
	Selectable value	Description	
	AM FULL	Set all parameter values again.	
AUTO MOD	AM BIAS	Only reset the motor reference value, but the other parameter values are not modified.	
	AM PIDb	Only reset PID value, but the other parameter values are not modified.	
	AM ZEb R	Only reset End point and Zero point of the valve, but the other parameter values are not modified.	
	Factory setting	AM FULL	
VAL OP/CL		current signal, it performs the function of opening we with the <b><up></up></b> or <b><down></down></b> buttons manually.	
VAL ZERO	Reset the ZERO point of the valve manually. Input 4mA current, press the <b><up></up></b> and <b><down></down></b> button to change the valve position, and press the <b><enter></enter></b> button to save the current valve position, then the positioner recognizes the current position as the valve ZERO point.		
VAL END	Reset the END point of the valve manually. Input 20mA current, press the <b><up></up></b> and <b><down></down></b> button to change the valve position, and press the <b><enter></enter></b> button to save the current valve position, then the positioner recognizes the current position as the valve END point.		
OUT ZERO	Reset the ZERO point of the feedback signal manually. Input <b>4mA</b> current signal, valve reaches zero position, after press the <b><up></up></b> or <b><down></down></b> button to adjust the value, until the 4mA feedback signal is output, and then press the <b><enter></enter></b> button to save.		



	NOTICE
	OUT ZERO setting must be done once after installing feedback module
OUT END	Reset the END point of the feedback signal manually. Input 20mA current signal, valve reaches end position, after press the <up> or <down> button to adjust the value, until the 20mA feedback signal is output, and then press the <enter>button to save.</enter></down></up>
	NOTICE
	OUT END setting must be done once after installing feedback module
IN ZERO	Reset the ZERO value of input signal manually  If <main in%=""> and <main ma=""> appear in the main menu differ from the actual input signal, execute the commands in this menu. Input 4mA current from this menu and press <enter> button to save.</enter></main></main>
	<u> </u>
	After replacing the main board or After program initialization, you must set the <b>IN ZERO</b> setting once.
IN END	Reset the END value of input signal manually. If <main in%=""> and <main ma=""> that appear in the main menu differ from the actual input signal, execute the commands of this menu. Input 20mA current from this menu and press <enter> button to save.</enter></main></main>
	<u></u> NOTICE
	After replacing the main board or After program initialization, you must set the <b>IN END</b> setting once.
BIAS25	The reference value of the motor whose valve stroke is 25% It is set automatically at auto-calibration, please do not modify this parameter value manually.
BIAS75	The reference value of the motor whose valve stroke is 75% It is set automatically at auto-calibration, please do not modify this parameter value manually.

#### 6.7.2 Submenus of PARAMETR

Submenus	Description




	l .			
DEAD bND	the problem can be solved allowed by the field.	allowable control error. curs due to high packing friction of the valve, I by increasing the value within the range the accuracy may be reduced.  0~100%		
	Factory setting	0.3%		
KP	If the setting value increas but it is more likely to have     If the setting value decrease positioner finds the target	e, the positioner finds the target point quickly hunting. se, the stability of the positioner is higher, but point slowly.		
	Range of settable value	0~500.0		
КІ	I control value, the integral value that adds the correction signal according to the error percentage to the existing correction signal.     If the setting value is too high, the time to reach the target point is accelerated, but the oscillation phenomenon is easy to occur.     If the setting value is too low, it will slow down the search for the target point.			
	Range of settable value	0~500.0		
KD	D control value, indicates the derivative value of the compensation signal based on the percentage of error allowance.  If the setting value is too high, it will slow down the search for the target point.  If the setting is too low, the oscillation is likely to occur.			
	Range of settable value	0~500.0		
GKP	<ul><li>process of reaching the target</li><li>The function is the same a</li></ul>	ality constant value of the control signal in the point as the KP control value but falls within the ± 1% alue, the GKP value is applied instead of the		
	Range of settable value	0~500.0		
GKI	the error percentage to the exist.  The function is the same a	ue that adds the correction signal according to sting correction signal.  Is the KI control value but falls within the ± 1% alue, the GKI value is applied instead of the KI		
	Range of settable value	0~500.0		
GKD	<ul><li>based on the percentage of err</li><li>The function is the same a</li></ul>	erivative value of the compensation signal for allowance.  It is the KD control value but falls within the ± 1% alue, the GKD value is applied instead of the  0~500.0		
KF	Control value to overcome valv			



Range of settable value	0~500.0
Factory setting	0

Set the characteristics of the valve control.



Input (mA)	Linear (%)	EQ1 (%)	EQ2 (%)	QO (%)	USER (%)
4	0	0	0	0	0
5	6.25	2.55	1.31	29.13	4
6	12.5	3.26	2.81	46.84	8
7	18.75	4.16	4.54	57.21	12
8	25	5.32	6.55	64.56	18
9	31.25	6.79	8.92	70.27	30
10	37.5	8.67	11.73	74.93	40
11	43.75	11.07	14.76	78.87	50
12	50	14.14	18.26	82.28	59
13	56.25	18.06	22.58	85.29	65
14	62.5	23.06	27.93	87.99	70
15	68.75	29.45	34.55	90.42	75
16	75	37.61	42.73	92.65	80
17	81.25	48.02	52.85	94.69	85
18	87.5	61.32	65.37	96.59	90
19	93.75	78.31	80.85	98.35	95
20	100	100	100	100	100

	CHAR LIN	Linear
Possible values	CHAR EQ1	Equal percentage (1/25)
	CHAR EQ2	Equal percentage (1/50)
	CHAR QUI	Quick Open
	CHAR USR	User defined17poins
Factory setting	CHAR LIN	

Realize the special flow curve by user-defined 17 points.

- In addition to the above Linear, Equal percentage, Quick open and other typical flow characteristics, the user can set the 4~20mA corresponding valve stroke position to achieve special flow curve control.
- To execute this function, <CHAR USR> must be set from the <CHAR> menus above.

#### **USER DEF**

**CHAR** 

Setting steps	Set the valve position according to the signal.
*USR P0	Set the valve position when the input signal is 4 mA.
*USE P1	Set the valve position when the input signal is 5 mA.
*USR P2	Set the valve position when the input signal is 6 mA.
*USR P3~16	Follow above steps for setting the valve position when the input signal is 7~19mA.
*USR P17	Set the valve position when the input signal is 20 mA.

#### 6.7.3 Submenus of DEVICE P

Submenus	Description
----------	-------------



	manually.	**	pe set to Single or Double		
		• NOTICE			
ACTU SNG	If the set value differs from the actuator type, the control characteristic may be degraded.				
	December of the second	ACTU SNG	Single type		
	Possible settings	ACTU DbL	Double type		
	Factory setting	6000L	ACTU SNG		
	r actory setting	6000R	ACTU DbL		
	Depending on the acmanually.	tuator type, it must l	pe set to Single or Double		
		<u></u> NOTIO	CE		
ACTU LIN	If the set value differs be degraded.	s from the actuator t	ype, the control characteristic ma		
	Descible settings	ACTU LIN	Linear type		
	Possible settings	ACTU ROT	Rotary type		
	Factory setting	6000L	ACTU LIN		
	1 actory setting	6000R	ACTU ROT		
		r is used to move the actuator.	set value, the valve is forced to e valve into its seat with the		
FORCE OP	0 0	Force close set po	Input Signal %		
FORCE OP	0  Range of settable val	Force close set po	Input Signal %		
FORCE OP	0	Force close set po	Input Signal %		



	forced to close.	al is lower than the set value, the valve is ed, residual pressure in the actuator chamber ased.		
FORCE CL	Range of settable values	0~100%		
	Factory setting	0.3%		
	Note	When the value set to 0%, this function is not applied.		
		perating speed of the valve. e, the slower the operating speed of the valve. ing phenomenon of small actuator can be		
DAMP	Range of settable values	0~100%		
	Factory setting	0%		
	Note	When the value set to 0%, this function is not applied.		
SPLIT ZR	value during the split range For example, if the set value 50%, 12mA corresponds to of the valve opening as sho in the right figure.  Range of settable values	e is 0%		
	Factory setting :	0%		
SPLIT END	Set the end point of the sign value during the split range  For example, if the set value 50%, 12mA corresponds to of the valve opening as showin the right figure.	nal control. 100		
	Range of settable values	0~100%		
	Factory setting :	0%		



	This parameter corrects th	o orror botu	oon I C	·D volue	and actual valva
	This parameter corrects the opening.	ie error betw	een LC	D value	and actual valve
		<b>⚠</b> NOTICE			
COMPENSA	This function should only be used with Linear type products and rotary products must be set to 0%.				
	Range of setting values	0~100%			
	Factory setting	6000L(Li	31 /		2%
		,	otary type) 0%		
	Change the action type of				
	Reverse Action Valve Stroke%	1	Direct Action		ect Action
	100		Valve St	Valve Stroke%	
ACT NORM	0 Input Signal mA 20mA		0 <u>20n</u>	0 20mA Input Signal mA	
	Possible settings	ACT REVE	:	Reverse Action	
	-	ACT NOR	NORM Direct Action		Action
	Factory setting	ACT REVE			
	Set the feedback signal from percentage as the valve s				
	Normal				Reverse
	100		1	00	
OUT NORM			Valve Stroke (%)	0	4mA
OUT NORM	0	Ī	Valve Stroke (%)	20mA O	4mA utput Signal (mA)
OUT NORM	0 4mA	OUT NORI	N	20mA O Norm	utput Signal (mA)
OUT NORM	4mA Output Signal (mA) Possible settings	Ī	N Value Stroke (%)	20mA O Norm	utput Signal (mA)
OUT NORM	0 4mA Output Signal (mA)	OUT NORI	M M	20mA O Norn Reve	nal action erse action
OUT NORM	Possible settings Factory setting  Adjusts the valve opening communication signal.	OUT NORI	M M	Norn Reve	nal action erse action
	Possible settings Factory setting  Adjusts the valve opening	OUT NORI OUR REVE OUT NORI in the forwa	M M	Norn Reve	nal action erse action rection of the HART



#### 6.7.4 Submenus of INFOMATN

You can find the following information through the submenus.


Submenus	Description			
MDL	Displays the model of the product.			
DEVI VER	Displays the version of device.			
HART VER	Displays the ver	sion of HART of	communication.	
POLL ADD	Displays the polling address of the device in HART communication.			
TRAVEL	Displays the accumulated total travel distance of the valve after the positioner has been used. (Unit: K%)  One full travel distance from full close to full open means 100% = 0.001K% For example, if the travel value is 1K%, this means that the valve has moved 1000 stroke percentages.			
OP TIME	Displays the total accumulated time when the valve is fully open. Unit: Second			
CL TIME	Displays the total accumulated time when the valve is fully close. Unit: Second			
	Display the valve opening value on the LCD in reverse direction.			
DSP NORM	Possible settings	DSP NORM	When the valve position is 0%, 0% is displayed on the LCD. When the valve position is 100%, 100% is displayed on the LCD.	
		DSP REVE	When the valve position is 0%, 100% is displayed on the LCD. When the valve position is 100%, 0% is displayed on the LCD.	
	Factory setting	DSP NORM		
TEMPERAT	Check the current ambient temperature of the positioner through the built-in temperature sensor.			
TEMP MAX	Displays the recorded lowest ambient temperature value after using the product.			
TEMP MIN	Displays the recorded lowest ambient temperature value after using the product.			



#### 6.7.5 Submenus of DIAGNOST

Submenus	Description			
ERR CODE	Displays the error code of the product. You can check the error code to resolve the problem. For details, refer to the explanation of error codes.(Page 49)			
	Set whether to execute the PST function.			
PST RUN	What is PST	Partial stroke testing (or PST), within the range of not affecting to the flow process, PST prevents the valve stem from sticking by moving the valve finely according to the set value and the period. In case of emergency, it can make the valve operate normally.		
	Possible settings	PST RUN	Execute the PST function	
		PST OFF	Do not execute PST function	
	Factory setting	PST OFF		

Set the necessary items to execute the PST function. The submenu of PST CFG is as below.



**PST CFG** 

Submenu	Description		
OP POINT	Sets start position when PST is supposed to start.  Valve initial position must be within ±1% from "0S  POINT". If not, wait until this condition is satisfied.		
	Default value	100%	
	Range of values	0~100%	
	Sets 1st target position of PST.		
1S POINT	Default value	90%	
	Range of values	0~100%	



		0.1.0.11		'( DOT
	ON DOINT	Sets 2nd targe	t posit	
	2N POINT	Default value		80%
		Range of value		0~100%
	INTERVAL	Set the waiting time after the first PST is performed and the second PST start.		
	INTERVAL	Default value		20 (Seconds)
		Range of value	s	1~100 (Seconds)
	LATENCY	Set the waiting time from "1S POINT" to "2N POINT" start.  After reaching the first target point "1S POINT", return to the initial position, wait for the "LATENCY" time specified by the user, and then move to the second "2S POINT" target point again.		
		Default value		10 (Seconds)
		Range of value	es	1~100 (Seconds)
	LMT TIME	Set the time allowed to reach the target point. If the time to reach the target value during the Perecution exceeds the "LMT TIME" time or there movement, the PST is considered to have failed the PST is immediately interrupted.		ne target value during the PST ne "LMT TIME" time or there is no is considered to have failed and
		Default value		5 (Seconds)
		Range of values		0~100 (Seconds)
		In the PST process, if the valve position exceeds the "EMERGNCY" set value, the PST function is stopped		
	EMERGNCY	Default value		15%
		Range of values		0~100%
	The LCD screen d	unction execution result value. displays the following information based on the set xecution results. See the table below to confirm the PST information.		
	Result value	PST REDy	Read	dy to run PST.
		PST SUCS	PST	succeed.
PST REDy		PST TOUT	"LMT TIME" failed to reach the target value within the set time value range.	
		PST FIXD	Valve	e has no action.
		PST DOUT	Exceed the target value by more than 1%.	
		PST EMRG	Exceeding the allowable valve position error range, beyond the "EMERGNCY" setting value.	



Setting Alarm 1 According to the set value, If the following conditions are satisfied, the alarm circuit is turned "ON", and LCD displayed A1 simbol. It remains "OFF" during normal operation. 0000 9~30V DC 4 | 1 **AL1 URGT** Load Load When the product has a serious problem **AL1 URGT** When the priority value is 0 in the error code. (Refer to page 48) When there is a potential problem When the product has a serious problem AL1 PRI 1 Possible settings When the priority value is 1 in the error code. (Refer to page 48) AL1 F\_CL When the valve is fully closed. AL1 F\_OP When the valve is fully opened. **AL1 NONE** Disable this alarm function Factory setting **AL1 URGT** Setting Alarm 2 According to the set value, If the following conditions are satisfied, the alarm circuit is turned "ON", and LCD displayed A2 simbol. **AL2 URGT** It remains "OFF" during normal operation. Same as AL1 URGT of above Possible settings **AL2 URGT** Factory setting



### 6.7.6 Submenus of EMERGNCy

Submenus	Description			
	Must enter a password to enter this menu. The password is set at the factory and cannot be changed by the user.			
PASSWORD	Factory setting	Press <b>UP &gt; ENTER &gt; DOWN &gt; UP</b> button sequentially.  (Press the 1321 buttons from left to right)		
	The position of the valve to be moved can be determined when an abnormality of the positioner is detected.			
	Possible settings	EMGy None	Do not take any action.	
EMGY OP		EMGy Open	Open the valve fully.	
		EMGy Close	Close the valve fully.	
		EMGy Stop	Stop the valve operation.	
	Factory setting EMGy None			
FULL OP	Open the valve fully by manual regardless of the input signal.			
FULL CL	Close the valve fully by manual regardless of the input signal.			
STOP	Maintains the current valve position regardless of the input signal.			
LOCK or	It locks to prevent changing all parameter values. When set to "LOCK", all commands such as auto-calibration, PID change, and set parameter values cannot be changed.			
UNLOCK	Passible setting	LOCK	Lock the program	
		UNLOCK	Unlock the program	
	Factory setting	UNLOCK		



# 7 Error code and Troubleshooting

- If there is a problem when installing or using the product, the \(\bigath \) symbol appears on the top of the LCD.
- If you enter the "ERR CODE" which is submenu of "DIAGNOST", an error code appears.
- Check the error code and refer to the table below to solve the problem.

No	Code	priority	Cause	Resolution
1	L	1	Valve End point is set too high	<ul> <li>Check whether the positioner is installed too high or low.</li> <li>Check whether the positioner is installed too far from the actuator. (Check the angle of use)</li> <li>Check the potentiometer gear and main gear are out of position. (The cause of the problem is strong vibration or external shock).</li> </ul>
2	К	1	Valve Zero point is set too low	<ul> <li>Check whether the positioner is installed too high or low.</li> <li>Check whether the positioner is installed too far from the actuator. (Check the angle of use)</li> <li>Check the potentiometer gear and main gear are out of position. (The cause of the problem is strong vibration or external shock).</li> </ul>
3	J	1	Valve End and Zero points are set too close. (Use angle is too small)	Increase the angle of use by repositioning the positioner closer to the actuator.
4	ı	1	Input current is below 3.8mA	Check input current signal
5	Н	1	Input current is over 22mA	Check input current signal
6	G	1	BIAS value exceeds limit	Run Auto-Calibration again (Accuracy is significantly reduced when used without auto-calibration)
7	F	1	Ambient temperature too high	Check ambient temperature
8	E	1	Ambient temperature too low	Check ambient temperature
9	D	1	Used over 100,000 cycles	Check positioner regularly
10	С	0	Used over 500,000 cycles	Check positioner regularly
11	В	0	Used over 1 million cycles	Replace positioner
12	Α	0	EEPROM damaged	Replace main PCB



## 8 Limited warranty and disclaimer

- This product has been fully inspected and shipped through a thorough quality inspection procedure. The manufacturer warranty period of the product is 12 months after the product is shipped from Jflow Controls.
- For any failure or damage reported within the warranty period which is clearly our responsibility, a replacement product or necessary parts will be provided. This limited warranty applies only to our product independently, and not to any other damage incurred due to the failure of the product.
- Using the device in a manner that does not fall within the scope of its intended use, disregarding this manual, using under qualified personnel, or making unauthorized alterations releases the manufacturer from liability for any resulting damage. This renders the manufacturer's warranty null and void.



4665 Interstate Drive \* Cincinnati, Ohio 45246 PH# 513.731.2900 \* Fax# 513.731.6939 www.jflowcontrols.com